



P.U ADHESIVE INSTRUCTIONS

1. Pour contents of Jerry Can “Activator” into Bucket “Adhesive Base”
2. Mix thoroughly for 2 minutes ensuring that the sides and bottom are thoroughly mixed.
3. Pour contents of bucket onto desired area and using a trowel spread adhesive evenly across surface ensuring a minimum of 1mm depth.
(ONCE MIXED DO NOT LEAVE VOLUME IN BUCKET AS IT WILL REDUCE WORKING TIME)

Mixing time	2 minutes
Working time	1 hour 30 minutes
Curing time	8 hours

4. Apply even pressure over the Tactiles laid ensuring that all the edges are in contact with the adhesive and follow the existing surface.